

For Operators, Installers and Technicians

Liquid Controls® Meter Lock-ups

Is your diesel dispenser showing any of the following symptoms?

- There is trickle flow (1-2 GPM) when the dispenser is authorized for full flow and the nozzle is open, but no gallonage is displayed?
- The meter output shaft is not turning even though there is flow from the nozzle?
- There is full flow for a short time, then flow drops to trickle flow, or no flow for no apparent reason?
- The meter was recently replaced, and is now locked-up just like the previous meter.
- When the meter has been removed, it appears to be “locked-up”.

If so, you need to inspect the components on the supply side of the meter:

- Pipe coming to the meter: Are there rust nodules or corrosion scale attached to the inside of the pipe? When you wipe your finger inside the pipe, can you easily loosen chunks of material?
- Spin-on-filter: Are there rust nodules or flakes visible?
- Strainer basket: Are there rust nodules or flakes in the basket? These often look like “coffee grounds”.
- Is the strainer’s wire-cloth mesh corroded, frayed, or missing pieces of mesh material?

If any of these symptoms or conditions are present, **DO NOT INSTALL** a replacement meter! The existing equipment may have been damaged by corrosive (acidic) material produced from contaminated fuel. This condition has been observed in systems dispensing Ultra Low Sulfur Diesel - ULSD. The product piping and equipment must be thoroughly inspected and repaired or replaced before a new meter can be installed. The LC® meter has low tolerance for ingested debris. A single rust nodule or strand of strainer mesh can jam a meter. (See photos on back.)

See the report by the Battelle Institute dated September 2012 for a comprehensive explanation of ULSD corrosion issues. The report is posted at:

<http://www.clean-diesel.org/pdf/ULSDStoringSystemCorrosion.pdf>

In a small minority of cases, there are other reasons for no flow or slow flow:

- Solenoid valve or driver board failure
- Clogged filter/strainer
- Low level of fuel in tank
- Miscellaneous debris has gotten into the piping or meter: metal or plastic bits, pipe dope, etc.
- Pulser is defective or not plugged in correctly - preventing proper display or valve authorization.

All product or company’s names, trade names, trademarks, parts numbers and part descriptions may be the trademarks of their respective owners, and are used for reference or identification purposes only. PMP does not claim any right to or affiliation with such owners. The PMP product described here is manufactured or remanufactured and sold by PMP and is not the product of any other identified manufacture



PMP CORPORATION
P.O. Box 422 - 25 Security Drive
Avon, CT 06001

A Veteran Owned and Managed Company

Local: 860-677-9656
Toll Free: 800-243-6628
Toll Free Fax: 888-674-0196
Web: www.pmp-corp.com
E-mail: sales@pmp-corp.com



© PMP CORP

LC meters that locked up due to debris.




Particles that caused meter to lockup



Rust particles that caused meter lockup




LC-M5 meter



LC Meter disassembled - internal view



Wire from strainer that caused meter lockup



This is corrosion of the meter bearing plate due to long term exposure to ULSD.

