



Installation Instructions for Compound Gear Stud Kit

Installation Instructions

PMP P/N 81011 – Compound Gear Stud Kit



- 1) Install compound gear stud through hole (K) in the base plate adjacent to the dollar drive shaft.
- 2) Install lock washer and nut (L) on the threaded end of the stud under the base plate.
- 3) Tighten nut firmly with a 7/16" wrench while gripping the shoulder (E) of the stud with pliers.

CAUTION: Do not grip the upper portion of the stud with pliers, as this may damage the gear bearing surface.

All product or company's names, trade names, trademarks, parts numbers and part descriptions may be the trademarks of their respective owners, and are used for reference or identification purposes only. PMP does not claim any right to or affiliation with such owners. The PMP product described here is manufactured or remanufactured and sold by PMP and is not the product of any other identified manufacturer.



PMP CORPORATION
P.O. Box 422 • 25 Security Drive
Avon, CT 06001

Local: 860-677-9656
Toll Free: 800-243-6628
Toll Free Fax: 888-674-0196
Web: www.pmp-corp.com
E-mail: sales@pmp-corp.com



© PMP CORP