Important Note for Installer and Operator
when replacing a TM-U950 printer
in a VeriFone® Ruby™ System

Do not turn the printer "ON" and "OFF". This will cause older Ruby systems to shutdown and newer Ruby systems to reboot.

This printer is shipped with the power switch in the "ON" position.

Leave the switch in the "ON" position when applying power to the system

1. Disconnect the AC power from the Power Brick. This can be done at the Power Brick or at the wall outlet.

2. Do not disconnect and reconnect the "Y" cable from the Power Brick with the AC power connected.

3. Connect the replacement printer
   a. Round connector from Power Brick into back of printer.
   b. Communications cable with blue connector into back of printer

4. Verify the printer switch is in the "ON" position.

5. Only now - reconnect the AC power to the Power Brick.

Exception:
> If the TM-U950 is powered by it's own PS180 power supply, the printer can be turned on and off without powering down the entire Ruby System.

All manufacturers' numbers, names, trade names, trademarks and descriptions used here are for reference purposes only. None of the rebuilt items listed here are the products of the identified manufacturers.

For Technical Assistance call 1-800-243-6628   website: www.pmp-corp.com

# FOLLOW THESE STEPS (1, 2, 3) WHEN REPLACING TM-U950 PRINTER

STEP 1

OLD TM-U950 PRINTER

DISPLAY

CASH DRAWER

POWER BRICK

AC PLUG

DISCONNECT AC POWER AT POWER BRICK OR AT WALL

STEP 2

PMP REMANUFACTURED TM-U950 PRINTER

DISPLAY

CASH DRAWER

POWER BRICK

AC PLUG

CONNECT NEW PRINTER POWER SWITCH ON

1 → **2**

3

STEP 3

PMP REMANUFACTURED TM-U950 PRINTER

DISPLAY

CASH DRAWER

POWER BRICK

AC PLUG

RECONNECT AC POWER

TO RUN A SELF-TEST OR RESET:

TM-U950 PRINTER

TO RUN A SELF-TEST OR RESET PRINTER, USE RESET BUTTON ON THE BLUE CONNECTOR INSTEAD OF CYCLING POWER WITH THE PRINTER POWER SWITCH