

PMP Wayne iGEM ISB (Intrinsically Safe Barrier)

Thank you for purchasing the enclosed PMP remanufactured Wayne iGEM ISB. This barrier is compatible with a variety of Wayne dispenser models. Confirm your application prior to installation.

This installation requires specific knowledge of respective equipment and you may need to refer to the OEM manuals before proceeding.

READ THIS GUIDE BEFORE YOU BEGIN



- Service station equipment has both electricity and hazardous, flammable and potentially explosive liquid. Failure to follow the precautions below and instructions in this guide may result in serious injury and death. Follow all rules, codes and laws that apply in your area.
- PMP shall not be liable for errors contained herein or for incidental or consequential damages in connection with furnishing, performance or use of this publication.
- PMP reserves the right to change product features or the information contained in this publication.
- Failure to install this product in accordance with OEM instructions and warnings will result in voiding of all warranties connected with this product and may damage the environment.



SAFETY PRECAUTIONS FOR INSTALLATION AND MAINTENANCE



- Only a person with knowledge and experience with service station equipment should perform this work.
- Always make sure ALL power to the equipment you are working with is turned OFF before starting any maintenance.
- Note that more than one disconnect switch may be required to de-energize the equipment for maintenance and servicing. Use a voltmeter to make sure ALL circuits in the dispenser are de-energized. Failure to do so may result in serious injury.
- Cordon off work area with barriers to avoid contact with traffic



SAFETY PRECAUTIONS FOR INSTALLATION AND MAINTENANCE CONT.



- Potentially explosive materials and or atmosphere. Take necessary precautions.



- Potentially flammable materials and or atmosphere. Take necessary precautions.

In the box

Qty	Description
1	Wayne ISB



Installation Prep



You must refer to the OEM manuals for detailed instructions on installation of this barrier



1. Confirm you have the correct barrier model for your application.

2. Turn-off power to the dispenser.



3. Block off the work area.



4. Open the dispenser and locate the barrier at the bottom of the electronics cabinet.

5. Disconnect the white and black connectors from the top of the barrier.

6. Remove the two screws mounting screws that hold the barrier in-place.



7. Carefully lift the barrier and remove the connectors from the bottom of the barrier. Make note of the connector locations.



8. Remove the barrier and reverse the process to install the new barrier.

9. Restore power to the dispenser and verify communications through the barrier

All product or company's names, trade names, trademarks, parts numbers and part descriptions may be the trademarks of their respective owners, and are used for reference or identification purposes only. PMP does not claim any right to or affiliation with such owners. The PMP product described here is manufactured or remanufactured and sold by PMP and is not the product of any other identified manufacturer.



PMP CORPORATION
P.O. Box 422 • 25 Security Drive
Avon, CT 06001

A Veteran Owned and Managed Company

Local: 860-677-9656
Toll Free: 800-243-6628
Toll Free Fax: 888-674-0196
Web: www.pmp-corp.com
E-mail: sales@pmp-corp.com



© PMP CORP